


## WG-30 Series Wall Guards



### Component Part Numbers:

- 1) ETC-30 Left/Right end cap
- 2) WGA-30 Aluminum retainer
- 3) OTC-30 Outside corner
- 4) Field mitered corner
- 5) WGV-30 Snap-on cover
- 6) SP-24 Rubber spacer

# Architectural Products Division

#### WG-30 Wall Guard Installation Instructions

Step 1: Determine top of wall guard and snap a chalk line 1/16" below to locate top of aluminum retainer, see fig

Store material in a clean dry place where the temperature is maintained above 50°F (10°C). Walls and Important:

> rooms should be maintained at a minimum of 65°F (18°C) for at least 48 hours prior to installation. Acclimate materials to normal building conditions for at least 24 hours before cutting and installing.

Step 2: Cut aluminum retainer. See Cutting Adjustment Diagrams and Schedule for adjustments to aluminum

retainer length at end caps, inside corners, and outside corners. Refer to Minimum Layout

Configurations for additional information. Aluminum should be mitered to accommodate outside corners

that are not 90° and all inside corners.

All cuts must be square and deburred. Important:

Step 3: Pre-drill clearance holes in aluminum retainer along the centerline of the retainer using a #15 (.180") bit for

#8 fastener or a #7 (.201") bit for #10 and 3/16" fasteners, see fig 2. Space holes at 32" on center. Adjust spacing to accommodate studs as necessary. Do not pre-drill at locations that will interfere with installation

of molded accessories.

Note: Drill point fasteners may be used without pre-drilling aluminum on drywall installations having continuous metal backer or studs. Continue to pre-drill at locations where no backing or stud is available.

Step 4: Pre-drill for attachment of molded accessories by inserting accessory in end of retainer. Press firmly to

ensure molded part is seated squarely against the aluminum.

Drywall Installation: Using the accessory as a template pre-drill clearance holes for mounting through to metal backer or stud or pre-drill pilot holes using #29 (.136") bit for #8 fastener or a #21 bit (.159") for #10

fastener for attaching accessories directly to aluminum, see fig 3.

Masonry Installation: Using the accessory as a template pre-drill clearance holes at mounting locations,

see fig 3.

Step 5: Fasten aluminum retainer and spacer to wall using hardware listed below. Align top edge of retainer with

Important: Begin installation of aluminum at corners allowing for molded accessories. Use the appropriate accessory

as a spacing template. See Cutting Adjustment Diagrams and Schedule for additional information. Do not fasten through holes pre-drilled for installation of molded accessories until accessories are installed in

step 6.

Drywall Installation: Fasten aluminum retainer to wall using hardware listed below. If it is necessary to install fasteners in locations where there is no metal backing or stud use pre-drilled aluminum as a template to mark and drill wall for Toggler® brand toggle bolts or plastic Alligator® insert in accordance with instructions provided with hardware.

Masonry Installation: Using the pre-drilled aluminum as a template, mark and drill the wall at all pre-drilled holes to accept plastic Alligator® insert or 3/16" Tapcon® or similar fastener. Drill in accordance with instructions provided with hardware.

Suggested hardware:

 Drywall with metal backing #8 or #10 Drill point drywall screw or #8 or #10 drill point pan head

or hex washer head sheet metal screw.

Plastic Alligator® insert with #8 or #10 pan head or hex washer • Drywall without stud or backing

head sheet metal screw or 3/16" Toggler® brand toggle bolts with

pan head machine screw.

Plastic Alligator® insert with #8 or #10 pan head or hex washer Masonry

head sheet metal screw or 3/16" hex washer head Tapcon®.

Step 6: Secure accessory components in place using hardware selected in step 5.

Caution: Use of a flat washer at accessory mounting tabs is recommended to prevent damage to molded

part caused by excessive tightening of the fastener.

Measure between accessories and cut the vinyl cover accordingly. Miter cut the cover for all angles not Step 7:


accommodated by the molded accessories. Cut cover so that it will span aluminum retainer butt joints.

Important: All cuts must be square and deburred.

Snap the cover in place. Install cover to span butt joints in retainer. Step 8:




## Cutting Adjustment Diagrams and Schedule



	Aluminum	Vinyl
	Retainer	Cover
End Cap	L - 2 1/8"	L - 1 7/8"
Outside Corner	L + 1/4"	L + 1/2"
Inside Corner	L - 1/2" (field miter)	L - 1/2" (field miter)

Important: install aluminum retainer and molded accessories before cutting the snap-on cover.

## Minimum Layout Configurations








fig 1




fig 2




fig 3